Original		Replacement	
	Power		Power
SOURCE	Source	TIMER AV	AV
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
TTX/MIX	TTX/MIX	REPEAT TEXT	Text
PRE-CH	PRE-CH	FAV PRE-CH	Pre Ch
	Vol+	+ VOL	Vol +
	Vol-	VOL −	Vol -
MUTE	Mute	MUTE	Mute

Original		Replacement	
CH LIST	CH List	DISC NAV LIST	List
P	P+	+ CH	Ch +
P	P-	CH −	Ch -
MENU	Menu	TOP MENU MENU	Menu
	Smart Hub	HOME SMART	Smart
GUIDE	Guide	-/-- GUIDE	Guide
TOOLS	Tools	SETTINGS OPT	Options
INFO	Info	DISPLAY INFO	Info
RETURN	Return	RETURN BACK	Back
EXIT	Exit	CLEAR EXIT	Exit
▲	Up	▲	Up
▼	Down	▼	Down
▶	Right	▶	Right
◀	Left	◀	Left
	Enter	OK	Ok
A	Red	A	Red
B	Green	B	Green

Original		Replacement		Original		Replacement	
C	Yellow	C	Yellow				
D	Blue	D	Blue				
SEARCH	Search	SEARCH TV/R	TV/R				
STATUS	Status	APP MEDIA	Media				
AD/SUBT.	AD/Subt.	AD SUBT	Subt				
E-MANUAL	E-Manual	E-MANUAL D.MENU	D. Menu				
RECOMMEND	Recommend	PICTURE FORMAT	Format				
3D	3D	ECO 3D	3D				
<<	<<	<<	<<				
I<<	I<<	I<<	I<<				
II	Pause	II	Pause				
>>	>>	>>	>>				
>>I	>>I	>>I	>>I				
●	Rec	REC MODE ●	Rec				
▶	Play	PLAY MODE ▶	Play				
■	Stop	■	Stop				