| Original | Replacement |
|---|---|
| Power | Power |
| Mute | Mute / Dimmer |
| Play | Play / Slow |
| Pause | Pause / Step / Freeze |
| Stop | Stop / Hold |
| Rec | Rec / Rec Mode |
| << | << / Tune- |
| >> | >> / Tune+ |
| Lang | Audio / Lang I/II |
| Source (Games) | Eject / Surround |
| Movie-Music-Phot | Picture / Format |
| [≡]. . | Zoom / Size |
| */O | Sleep / Timer |
| TV | TV/Radio / |
| Q. Menu | D. Menu / Top |
| [-O-] | Setup / OPT / |
| [≡]/Text | Text / Goto |

| Original | Replacement |
|---|---|
| Menu | Menu / Home |
| Up | Up |
| i | Info / Angle |
| Left | Left |
| OK | OK |
| Right | Right |
| Exit | Exit / Cancel / Clear |
| Down | Down |
| Back | Back / Return |
| Vol + | Vol + |
| World (Violet) | Smart / List |
| PR+ | CH+ / Page+ |
| Vol - | Vol - |
| */Q | Display / Media |
| PR- | CH- / Page- |
| 1 | 1 |
| 2 | 2 |

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| | 3 | CD - STB 3 | 3 | | |
| | 4 | VIDEO 4 | 4 | | |
| | 5 | TAPE 5 | 5 | | |
| | 6 | TUNER 6 | 6 | | |
| | 7 | AUX - HDD 7 | 7 | | |
| | 8 | USB 8 | 8 | | |
| | 9 | BLUETOOTH 9 | 9 | | |
| | Guide | -/-- GUIDE EPG | Guide / EPG / -/-- | | |
| | 0 | HDMI - SAT 0 | 0 | | |
| | Red | NETFLIX SEARCH | Red / Netflix / Search | | |
| | Green | APP REPEAT | Green / APP / Repeat | | |
| | Yellow | YouTube REPEAT A-B | Yellow / YouTube / Repeat | | |
| | Blue | Prime Video RANDOM | Blue / Prime Video / Random | | |
| | Recall | SHIFT + RETURN BACK | Shift + Back / Return | | |
| | | | | | |
| | | | | | |
| | | | | | |