Mandis shop

Sharp RRMCG0047SJSA

Original		Replacement	
G1	CD 1	1	1
G2	CD 2	2	2
G3	CD 3	3	3
MEMORY /SET	Memory Set	TOP MENU MENU	Menu
CD II	Pause CD	II	Pause
■	Stop	■	Stop
▶	Play/Back	PLAY MODE ▶	Play
CLEAR	Clear	CLEAR EXIT	Exit
RANDOM	Random	APP MEDIA	Media
⏮ ◀◀	I<<</Preset	⏮	I<<
▶▶ ⏭	>>I/Preset Up	⏭	>>I
EQUALIZER MODE	Equalizer Mode	AD SUBT	Subt
CLOCK	Clock	TIMER AV	AV
TIMER	Timer	REPEAT TEXT	Text
SLEEP	Sleep	PROG SLEEP	Sleep
CD	CD	C	Yellow
TUNER (BAND)	Tuner/Band	A	Red

Original		Replacement	
TAPE	Tape	B	Green
ON/ STAND-BY	On/Standby	⏻	Power
X-BASS	X-Bass	SOUND DUAL	Dual
VOL	Vol-	VOL −	Vol -
UME	Vol+	+ VOL	Vol +

https://alle-fernbedienungen.de/en/Sharp/1039578-2511-replacement-remote-control-for-Sharp-RRMCG0047SJSA.html