| Original | | Replacement | |
|---|---|---|---|
| ON/STAND-BY | On/Standby | | Power |
| OPEN/CLOSE | Open/Close | ZOOM | Eject |
| MEMORY | Memory | FAV PRE-CH | Pre Ch |
| CLEAR | Clear | CLEAR EXIT | Exit |
| CLOCK/TIMER | Clock/Timer | TIMER AV | AV |
| SLEEP | Sleep | PROG SLEEP | Sleep |
| REPEAT | Repeat | REPEAT TEXT | Text |
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 2 |
| 3 | 3 | 3 | 3 |
| 4 | 4 | 4 | 4 |
| 5 | 5 | 5 | 5 |
| 6 | 6 | 6 | 6 |
| 7 | 7 | 7 | 7 |
| 8 | 8 | 8 | 8 |
| 9 | 9 | 9 | 9 |
| 0 | 0 | 0 | 0 |

| Original | | Replacement | |
|---|---|---|---|
| 10+ | 10+ | GUIDE | Guide |
| BASS/TREBLE | Bass/Treble | SETTINGS OPT | Options |
| X-BASS | X-Bass | SOUND DUAL | Dual |
| RANDOM | Random | AD SUBT | Subt |
| TUNING | <<I<<Tuning | | I<< |
| TUNING | Tuning | | >>I |
| FOLDER | Folder | RETURN BACK | Back |
| DEMO/ DIMMER | Demo/Dimmer | ECO 3D | 3D |
| PRESET | Preset Up | | Up |
| PRESET | Preset Down | | Down |
| ENTER | Enter | OK | Ok |
| VOL | Vol+ | VOL + | Vol + |
| VOL | Vol- | VOL − | Vol - |
| | Mute | MUTE | Mute |
| CD | CD | C | Yellow |
| USB | USB | D | Blue |
| TUNER BAND | Band/Tuner | B | Green |

| Original | | Replacement | |
|---|---|---|---|
| AUDIO/LINE INPUT | Input/Audio/Line | A | Red |
| iPod | iPod | HOME SMART | Smart |
| DISPLAY (TV OUT) | (Tv Out)/Display | SEARCH TV/R | TV/R |
| MENU | Menu | TOP MENU MENU | Menu |
| ►/II | Play/Pause Ipod | II | Pause |
| DISPLAY | Display CD/USB | DISPLAY INFO | Info |
| ■ | Stop CD/USB | ■ | Stop |
| ►/II | Play/Pause | PLAY MODE ► | Play |
| NETWORK | Network | APP MEDIA | Media |

| Original | Replacement |
|---|---|
| | |