Original		Replacement	
ON/ STAND-BY	On / Stand-By	Power	
MEMORY	Memory	DISC NAV LIST	List
CLEAR/ DIMMER	Clear / Dimmer	CLEAR EXIT	Exit
TUNER	Tuner	A	Red
CD	CD	B	Green
CD	CD Stop		Stop
CD	CD Play / Paus	PLAY MODE	Play
CD	CD Play / Paus		Pause
AUDIO IN USB	USB / Audio I	C	Yellow
USB	USB Stop	SHIFT +	Shift + Stop
USB	USB Play / Pause	SHIFT + PLAY MODE	Shift + Play
USB	USB Play / Pause	SHIFT +	Shift + Pause
PLAY MODE	Play Mode	SETTINGS OPT	Options
TUNING	Up / Tuning Up		Up
TUNING	Down / Tuning		Down
PRESET	Right / >>I / >> Preset Up		Right
PRESET	Right / >>I / >> Preset Up		>>I

Original		Replacement	
PRESET	Right / >>I / >> Preset Up		>>
PRESET	Left / I<< / << Preset Down		<<
PRESET	Left / I<< / << Preset Down		I<<
PRESET	Left / I<< / << Preset Down		Left
DISPLAY	Display	DISPLAY INFO	Info
FOLDER	Folder	HOME SMART	Smart
CLOCK /TIMER	Clock / Timer	PROG SLEEP	Sleep
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0

Original		Replacement	
+10	+10	-/-- GUIDE	Guide
BASS/ TREBLE	Equalizer Mode	SOUND DUAL	Dual
X-BASS / DEMO	X-Bass / Demo	AD SUBT	Subt
VOLUME −	Volume -	VOL −	Vol -
VOLUME +	Volume +	+ VOL	Vol +

Original	Replacement