Original		Replacement	
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
FUNCTION	Function	HOME MENU	Menu / Home
	Power		Power
CD	Play CD	SLOW	Play / Slow
CD	Play CD	CD-STB 3	3
D.SKIP	D.Skip	SURROUND	Eject / Surround
TUNER/BAND	Tuner/Band	TUNER 6	6
TUNER/BAND	Tuner/Band	PROGRAM TV/RADIO	TV/Radio /
CHECK	Check	ANGLE INFO	Info / Angle
DECK A	< > Deck A	TAPE 5	5
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
DECK A	< > Deck A	TV 1	1
DECK B	< > Deck B	DVD 2	2
TUNING	I<<</Tuning-	PRESET-	I<< / Preset-
TUNING	I<<</Tuning-	SHIFT + TUNE-	Shift + << /
TUNING	>>I/Tuning+	SHIFT + TUNE+	Shift + >> /
TUNING	>>I/Tuning+	PRESET+	>>I / Preset+

Original		Replacement	
	Stop	HOLD	Stop / Hold
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Play MD	SHIFT + SLOW	Shift + Play /
	Play MD	VIDEO 4	4
	Pause MD	SHIFT + STEP-FREEZE	Shift + Pause / Step /
	Stop MD	SHIFT + HOLD	Shift + Stop /
FILE SELECT	Up/File Select		Up
LOOP	Left/Loop		Left
ON/OFF	On/Off	OK	OK
FLASH	Right/Flash		Right
	Down		Down
PRO LOGIC ON/OFF	Pro logic On/Off	TITLE SOUND	Sound / Title
T.TONE ON/OFF	T Tone On/Off	LANG I/II AUDIO	Audio / Lang I/II
DSP	DSP	EQ SUBTITLE	Subtitle / EQ
CENTER LEVEL	Center Level +	LIST SMART	Smart / List

Original	Replacement	Original	Replacement
Rear Level +	CH+ / Page+		
Volume+	Vol +		
Center Level -	Display / Media		
Rear Level -	CH- / Page-		
Volume-	Vol -		