Original		Replacement	
BASS BOOST	Bass Bost	EQ SUBTITLE	Subtitle / EQ
DISPLAY	Display	MEDIA DISPLAY	Display / Media
I/⏻	Power	⏻	Power
1	Tune Memory N.	TV 1	1
2	Tune Memory N.	DVD 2	2
3	Tune Memory N.	CD - STB 3	3
4	Tune Memory N.	VIDEO 4	4
5	Tune Memory N.	TAPE 5	5
6	Tune Memory N.	TUNER 6	6
FM	FM	SHIFT + TUNER 6	Shift + 6
AM	AM	SHIFT + TV 1	Shift + 1
AUDIO IN	AUDIO IN	SHIFT + DVD 2	Shift + 2
CD	CD	SHIFT + CD - STB 3	Shift + 3
USB	USB	USB 8	8
USB	USB	SHIFT + USB 8	Shift + 8
TUNER MEMORY	Tuner Memory	LIST SMART	Smart / List
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear

Original		Replacement	
TUNE+	Up / Folder+	▲	Up
PLAY MODE/ TUNING MODE	Play Mode / Tuning Mode	OPT-TOOLS SETUP	Setup / OPT /
REPEAT/ FM MODE	Repeat / FM Mode	APP REPEAT	Green / APP / Repeat
◀	Left	◀	Left
✥	OK	OK	OK
▶	Right	▶	Right
VOLUME +	Volume+	+ VOL	Vol+
RETURN	Return	RETURN BACK	Back / Return
▼	Down / Folder-	▼	Down
TIMER MENU	Timer Menu	HOME MENU	Menu / Home
—	Volume-	VOL —	Vol-
⏮	I<< / -	PRESET- ⏮	I<< / Preset-
⏸	Pause	STEP - FREEZE ⏸	Pause / Step / Freeze
+ ⏭	>>I / +	PRESET+ ⏭	>>I / Preset+
◀◀	<<	TUNE- ◀◀	<< / Tune-
▶	Play	SLOW ▶	Play / Slow
▶▶	>>	TUNE+ ▶▶	>> / Tune+

Original		Replacement	
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
■	Stop	HOLD ■	Stop / Hold

Original	Replacement