Mandis shop

Sony RMT-845

Original		Replacement		Original		Replacement	
TC RESET	TC Reset	CLEAR EXIT CANCEL	Exit / Cancel / Clear	DISPLAY	Display	MEDIA DISPLAY	Display / Media
DATA CODE	Data Code	LIST SMART	Smart / List		Down		Down
	Start/Stop		Power				
SCAN	◁ Scan/Slow	TUNE-	<< / Tune-				
SLOW	Scan/Slow ▷	TUNE+	>> / Tune+				
T	T	CH PAGE	CH+ / Page+				
	⏮	PRESET-	⏮ / Preset-				
	⏭	PRESET+	⏭ / Preset+				
PLAY	Play	SLOW	Play / Slow				
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze				
W	W	CH PAGE	CH- / Page-				
STOP	Stop	HOLD	Stop / Hold				
	Up		Up				
MODE	Mode	FORMAT PICTURE	Picture / Format				
	Left		Left				
ENTER	Enter	OK	OK				
	Right		Right				

https://aliexpress.com/item/1005001617953634-replacement-remote-control-for-Sony-RMT-845-RMT-835-RMT-833.html