Original		Replacement	
	Power		Power
	HDMI / Control	HOME SMART	Smart
	Rec	REC MODE	Rec
	Stop		Stop
	Play	PLAY MODE	Play
	Pause		Pause
	<<		<<
	>>		>>
	I <<		I <<
	>>I		>>I
ZOOM	Red/ Zoom/ ↑↓	A	Red
REPEAT	Green/ Repeat / ↓	B	Green
ROOT	Yellow/ Root	C	Yellow
TITLE	Blue/ Title	D	Blue
SCREEN	Screen	PICTURE FORMAT	Format
LANG	Lang	SOUND DUAL	Dual
SUBTITLE	Subtitle	AD SUBT	Subt

Original		Replacement	
	Internet / PIP	APP MEDIA	Media
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
TEXT	Text	REPEAT TEXT	Text
INFO	Info	DISPLAY INFO	Info
SOURCE	Source	TIMER AV	AV
OK	OK	OK	Ok
	Up		Up
	Down		Down

Original		Replacement		Original		Replacement	
	Right		Right				
	Left		Left				
P+	P+	+ CH	Ch +				
P-	P-	CH −	Ch -				
V+	Vol +	+ VOL	Vol +				
V-	Vol -	VOL −	Vol -				
MENU	Menu	TOP MENU MENU	Menu				
	Mute	MUTE	Mute				
RETURN	Return	RETURN BACK	Back				
SWAP	Swap	FAV PRE-CH	Pre Ch				
FAV	FAV	SHIFT + FAV PRE-CH	Shift + Pre Ch				
EPG	EPG	-/-- GUIDE	Guide				
SLEEP	Sleep	PROG SLEEP	Sleep				
SEARCH MODE	Search Mode	SHIFT + TIMER AV	Shift + AV				
	Ball / Angle	SETTINGS OPT	Options				
DISPLAY	Display	SHIFT + DISPLAY INFO	Shift + Info				
PRESETS	Presets	SEARCH TV/R	TV/R				