Original	Replacement	Original	Replacement
Power	Power	Mute	Mute / Dimmer
1	1	P-	CH- / Page-
2	2	Menu/DVD	Menu / Home
3	3	Exit	Exit / Cancel / Clear
4	4	Up	Up
5	5	Left	Left
6	6	OK	OK
7	7	Right	Right
8	8	Top Menu	Guide / EPG / -/--
9	9	Top Menu	D. Menu / Top
Recall	Back / Return	Down	Down
0	0	Set Up	TV/Radio /
Source	AV / Input / RDS	Set Up	Fav / Marker / PC
Vol +	Vol +	Set Up	Setup / OPT /
Audio	Audio / Lang I/II	Red	Red / Netflix / Search
P+	CH+ / Page+	Green	Green / APP / Repeat
Vol -	Vol -	Yellow	Yellow / YouTube / Repeat

Original	Replacement	Original	Replacement
Blue	Blue / Prime Video / Random		
[<>]	Picture / Format		
→[/]←	Display / Media		
[i +]/[≡i]	Info / Angle		
Text	Text / Goto		
Subtitle / Open/Close	Subtitle / EQ		
Subtitle / Open/Close	Eject / Surround		
O)I/II / Stop	+ Shift + Audio / Lang I/II		
O)I/II / Stop	Stop / Hold		
O)I/II / Stop	Sound / Title		
Play/[≡o]	Play / Slow		
II/II>/[▼]	Pause / Step / Freeze		
I<</[≡?]	I<< / Preset-		
<</[≡+]	<< / Tune-		
>>/[≡♦]	>> / Tune+		
>>I/[O]/[≡X]	>>I / Preset+		

Original	Replacement	Original	Replacement
Power	Power	Menu/DVD	Menu / Home
1	1	Up	Up
2	2	Left	Left
3	3	OK	OK
4	4	Right	Right
5	5	Top Menu	D.Menu / Top
6	6	Down	Down
7	7	Set Up	Setup / OPT /
8	8	[<>]	Picture / Format
9	9	→[/]←	Display / Media
DVD RTN	Back / Return	[i+]/[≡i]	Info / Angle
0	0	Open/Close / Subtitle	Subtitle / EQ
Source	AV / Input / RDS	Open/Close / Subtitle	Eject / Surround
Vol +	Vol +	Stop	Stop / Hold
Audio	Audio / Lang I/II	Play/[≡o]	Play / Slow
Vol -	Vol -	II/II>/[▼]	Pause / Step / Freeze
Mute	Mute / Dimmer	I<</[≡?]	I<< / Preset-

Original	Replacement	Original	Replacement
<</ [≡+]	TUNE- << / Tune-		
>>/ [≡♦]	TUNE+ >> / Tune+		
>>I / [O] / [≡X]	PRESET+ >>I / Preset +		

Original	Replacement	Original	Replacement
Power	Power	Pause	Pause / Step / Freeze
1	1	<<	<< / Tune-
2	2	>>	>> / Tune+
3	3		
4	4		
5	5		
6	6		
7	7		
8	8		
9	9		
0	0		
Source	AV / Input / RDS		
P+	CH+ / Page+		
P-	CH- / Page-		
Eject	Eject / Surround		
Stop	Stop / Hold		
Play	Play / Slow		