| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| | Red | NETFLIX SEARCH | Red / Netflix / Search |
| | Green | APP REPEAT | Green / APP / Repeat |
| | Yellow | YouTube REPEAT A-B | Yellow / YouTube / Repeat |
| | Blue | Prime Video RANDOM | Blue / Prime Video / Random |
| M | Menu | HOME MENU | Menu / Home |
| P<P | P<P | LIST SMART | Smart / List |
| | Up | | Up |
| | Left | | Left |
| OK | Ok | OK | OK |
| | Right | | Right |
| | Down | | Down |
| AV | AV | RDS AV INPUT | AV / Input / RDS |
| TV/ | Tv/R | PROGRAM TV/ RADIO | TV/Radio / |
| INFO i | Info | ANGLE INFO | Info / Angle |
| I-II | I-II | LANG I/II AUDIO | Audio / Lang I/II |
| + V | Vol + | + VOL | Vol + |

| Original | | Replacement | |
|---|---|---|---|
| + P | P+ | + CH PAGE | CH+ / Page+ |
| V − | Vol - | VOL − | Vol - |
| | Mute | DIMMER MUTE | Mute / Dimmer |
| P − | P- | CH PAGE − | CH- / Page- |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD-STB 3 | 3 |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| 7 | 7 | AUX-HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| PP | PP | RETURN BACK | Back / Return |
| 0 | 0 | HDMI-SAT 0 | 0 |
| -/-- EXIT | -/-- Exit | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| -/-- EXIT | -/-- Exit | SHIFT + -/-- GUIDE EPG | Shift + Guide / EPG / -/-- |

| Original | | Replacement | | Original | | Replacement | |
|---|---|---|---|---|---|---|---|
| | [ ≡] / Text | GOTO TEXT | Text / Goto | | | | |
| | [ ≡o] | TUNE- | << / Tune- | | | | |
| | [ ≡+] | TUNE+ | >> / Tune+ | | | | |
| | [ ≡x] | PRESET- | I << / Preset- | | | | |
| | [ . ≡] / [ *] | PRESET+ | >>I / Preset+ | | | | |
| WIDE | [ ≡♦] / [ +] / Wide | FORMAT PICTURE | Picture / Format | | | | |
| PC | [ ≡?] / PC | PC FAV MARKER | Fav / Marker / PC | | | | |
| GUIDE | [ ≡i ] / Guide | -/-- GUIDE EPG | Guide / EPG / -/-- | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |