Original	Replacement	Original	Replacement
Open / Close	Eject / Surround	6	6
Power	Power	Angle	Info / Angle
Mute	Mute / Dimmer	7	7
System	Menu / Home	8	8
Go To	Text / Goto	9	9
L/R	D.Menu / Top	Digest	Sleep / Timer
Program	TV/Radio /	0	0
Repeat	Green / APP / Repeat	10+	Guide / EPG / -/--
Rep A-B	Yellow / YouTube / Repeat	Clear	Exit / Cancel / Clear
Random	Blue / Prime Video / Random	I<< Skip	I<< / Preset-
Audio	Audio / Lang I/II	Skip >>I	>>I / Preset+
1	1	<< Scan	<< / Tune-
2	2	Scan >>	>> / Tune+
3	3	Play	Play / Slow
Subtitle	Subtitle / EQ	Pause	Pause / Step / Freeze
4	4	Stop	Stop / Hold
5	5	Title	Sound / Title

Original		Replacement		Original		Replacement	
PBC	PBC	FORMAT PICTURE	Picture / Format				
	Up		Up				
	Left		Left				
SELECT	Select	OK	OK				
	Right		Right				
OSD	OSD	MEDIA DISPLAY	Display / Media				
	Down		Down				
RETURN	Return	RETURN BACK	Back / Return				
ZOOM	Zoom	SIZE ZOOM	Zoom / Size				
SLOW	Slow	SHIFT + SLOW	Shift + Play /				
STEP	Step	SHIFT + STEP - FREEZE	Shift + Pause / Step /				
RESUME	Resume	REC MODE	Rec / Rec Mode				
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /				
FUNCTION	Function	LIST SMART	Smart / List				
-	-	VOL -	Vol -				
+	+	+ VOL	Vol +				