







**Originalfernbedienung    Ersatzfernbedienung**

|   |          |   |                            |
|---|----------|---|----------------------------|
|    | Power    |    | Power                      |
|    | AV Mode  |    | AV / Input / RDS           |
|    | Radio    |    | TV/Radio /                 |
|    | Surround |    | Eject / Surround           |
|    | DTV      |    | Shift + TV/Radio / Program |
|    | Mute     |    | Mute / Dimmer              |
|    | 1        |    | 1                          |
|    | 2        |    | 2                          |
|    | 3        |    | 3                          |
|    | Vol+     |    | Vol+                       |
|   | 4        |   | 4                          |
|  | 5        |  | 5                          |
|  | 6        |  | 6                          |
|  | Vol-     |  | Vol-                       |
|  | 7        |  | 7                          |
|  | 8        |  | 8                          |
|  | 9        |  | 9                          |




















**Originalfernbedienung    Ersatzfernbedienung**

|   |           |   |                           |
|---|-----------|---|---------------------------|
|    | PR+       |    | CH+ / Page+               |
|    | Recall    |    | Back / Return             |
|    | 0         |    | 0                         |
|    | Source    |    | Shift + AV / Input / RDS  |
|    | PR-       |    | CH- / Page-               |
|    | [<>]      |    | Picture / Format          |
|    | I/II/I+II |    | Zoom / Size               |
|    | [i+]      |    | Info / Angle              |
|    | Sleep     |    | Sleep / Timer             |
|    | EPG       |    | Guide / EPG / -/--        |
|   | ESG       |   | Setup / OPT /             |
|  | DTV Menu  |  | Shift + D.Menu / Top Menu |
|  | [≡]/Text  |  | Text / Goto               |
|  | Up        |  | Up                        |
|  | Menu      |  | Menu / Home               |
|  | Left      |  | Left                      |
|  | OK        |  | OK                        |





**Originalfernbedienung**    **Ersatzfernbedienung**

|   |        |   |                             |
|---|--------|---|-----------------------------|
|    | Right  |    | Right                       |
|    | END    |    | Exit / Cancel / Clear       |
|    | Down   |    | Down                        |
|    | Return |    | Shift + Back / Return       |
|    | [≡?]   |    | Shift + Info / Angle        |
|    | [≡+]   |    | Stop / Hold                 |
|    | [...]  |    | Subtitle / EQ               |
|    | [≡o]   |    | D.Menu / Top                |
|    | Red    |    | Red / Netflix / Search      |
|   | Green  |   | Green / APP / Repeat        |
|  | Yellow |  | Yellow / YouTube / Repeat   |
|  | Blue   |  | Blue / Prime Video / Random |
|   |        |   |                             |
|   |        |   |                             |
|   |        |   |                             |
|   |        |   |                             |
|   |        |   |                             |
|   |        |   |                             |
|   |        |   |                             |
|   |        |   |                             |
|   |        |   |                             |
|   |        |   |                             |
|   |        |   |                             |

**Originalfernbedienung**    **Ersatzfernbedienung**

|  |  |  |  |
|--|--|--|--|
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |

