





































































Originalfernbedienung Ersatzfernbedienung

| | | | |
|---|---------------|---|--------|
|  | Power |  | Power |
|  | TV/RAD |  | TV/R |
|  | Bollywood |  | Format |
|  | [↔]/Ratio |  | 3D |
|  | Away/Mosquito |  | Media |
|  | Source |  | AV |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |
|  | 0 |  | 0 |
|  | List |  | List |

Originalfernbedienung Ersatzfernbedienung

| | | | |
|---|--------|---|---------|
|  | Info |  | Info |
|  | Vol+ |  | Vol + |
|  | Vol- |  | Vol - |
|  | Mute |  | Mute |
|  | FAV |  | Pre Ch |
|  | Guide |  | Guide |
|  | P+ |  | Ch + |
|  | P- |  | Ch - |
|  | Back |  | Back |
|  | Exit |  | Exit |
|  | Home |  | Smart |
|  | * |  | Menu |
|  | Q.Menu |  | D. Menu |
|  | Text |  | Text |
|  | T.OPT |  | Options |
|  | Up |  | Up |
|  | Down |  | Down |



