

































































**Originalfernbedienung    Ersatzfernbedienung**

|   |             |   |       |
|---|-------------|---|-------|
|    | Power       |    | Power |
|    | Mute        |    | Mute  |
|    | 1           |    | 1     |
|    | 2           |    | 2     |
|    | 3           |    | 3     |
|    | 4           |    | 4     |
|    | 5           |    | 5     |
|    | 6           |    | 6     |
|    | 7           |    | 7     |
|    | 8           |    | 8     |
|   | 9           |   | 9     |
|  | 0           |  | 0     |
|  | TV / Radio  |  | TV/R  |
|  | Last        |  | Back  |
|  | Red / Audio |  | Red   |
|  | Red / Audio |  | Dual  |
|  | Green / Sub |  | Green |

**Originalfernbedienung    Ersatzfernbedienung**

|   |             |   |        |
|---|-------------|---|--------|
|    | Green / Sub |    | Subt   |
|    | Yellow      |    | Yellow |
|    | Blue        |    | Blue   |
|    | Vol-        |    | Vol -  |
|    | Vol+        |    | Vol +  |
|    | Info        |    | Info   |
|    | Exit        |    | Exit   |
|    | EPG         |    | Guide  |
|    | Smart       |    | Smart  |
|    | File        |    | Media  |
|   | Menu        |   | Menu   |
|  | Up          |  | Up     |
|  | Left        |  | Left   |
|  | OK          |  | Ok     |
|  | Right       |  | Right  |
|  | Down        |  | Down   |
|  | TTX         |  | Text   |



