





































Originalfernbedienung Ersatzfernbedienung

| | | | |
|---|--------|---|--------|
|  | Power |  | Power |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |
|  | 0 / AV |  | 0 |
|  | 0 / AV |  | AV |
|  | Mute |  | Mute |
|  | PIP |  | Smart |
|  | Red |  | Red |
|  | Green |  | Green |
|  | Yellow |  | Yellow |

Originalfernbedienung Ersatzfernbedienung

| | | | |
|---|---------------|---|--------------|
|  | Blue / Freeze |  | Blue |
|  | Mosaic |  | Media |
|  | Recall |  | Back |
|  | Up / P+ |  | Up |
|  | Up / P+ |  | Ch + |
|  | Down / P- |  | Down |
|  | Down / P- |  | Ch - |
|  | Right / V+ |  | Right |
|  | Right / V+ |  | Vol + |
|  | Left / V- |  | Left |
|  | Left / V- |  | Vol - |
|  | Menu |  | Menu |
|  | OK |  | Ok |
|  | 16:9 |  | Format |
|  | Text |  | Text |
|  | Text Mix |  | Shift + Text |
|  | Text Subpage |  | Subt |



