





































Originalfernbedienung Ersatzfernbedienung

	Power		Power
	D/A		TV/R
	Source		AV
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Last		Pre Ch
	Info		Info
	FAV		Shift + Pre Ch
	Picture		Shift + Format



Originalfernbedienung Ersatzfernbedienung

	Sound		Shift + Dual
	Vol +		Vol +
	Vol -		Vol -
	Mute		Mute
	CH +		Ch +
	CH -		Ch -
	Menu		Menu
	EPG		Guide
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	I / II		Dual
	Still		List
	Zoom		Eject
	Exit		Exit

























Originalfernbedienung Ersatzfernbedienung

	Radio / Browse		Shift + TV/R
	T.Shift / Rotate		Shift + AV
	Audio / Page up		Shift + Ch +
	Audio / Page up		Shift + Subt
	Subtitle / Page down		Subt
	Subtitle / Page down		Shift + Ch -
	D/EMP		Smart
	Media / PVR		Media
	Play / Pause		Play
	Play / Pause		Pause
	Stop		Stop
	Red / <<<		Red
	Red / <<<		<<<
	Green / >>>		Green
	Green / >>>		>>>
	Yellow / I<<<		Yellow
	Yellow / I<<<		I<<<

Originalfernbedienung Ersatzfernbedienung

	Blue / >>>I		Blue
	Blue / >>>I		>>>I
	Text / Setup		Text
	Size		Format
	Reveal		Options
	Cancel		Back
	Hold / Sleep		Sleep
	Index		Shift + Info
	Sub.Code /		3D
	Mix		Shift + Options

