





























Originalfernbedienung Ersatzfernbedienung

	Standby		Power
	Auto Setup		Options
	Computer 1		1
	Computer 2		2
	HDMI		3
	Video		4
	S-Video		5
	Component		6
	Up		Up
	Left		Left
	Select		Ok
	Right		Right
	Down		Down
	Menu		Menu
	Screen		Media
	Keystone		Smart
	Info		Info

Originalfernbedienung Ersatzfernbedienung

	Freeze		<<
	AV Mute		AV
	P-Timer		Sleep
	Lamp		List
	Image		Format
	Mute		Mute
	3D		3D
	D.Zoom+		Ch +
	D.Zoom-		Ch -
	Vol+		Vol +
	Vol-		Vol -

