



Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Sleep		Sleep
	TAPE A <<		<<
	TAPE A <		Left
	TAPE A Stop		Ok
	TAPE A >		Right
	TAPE A >>		>>
	TAPE B <		Shift + Left
	TAPE B <<		Shift + <<
	TAPE B Stop		Shift + Ok
	TAPE B >		Shift + Right
	TAPE B >>		Shift + >>
	TAPE B Pause		Shift + Pause
	TAPE B Rec		Shift + Rec
	CD I<<		I<<
	CD >>I		>>I
	CD Stop		Stop

Originalfernbedienung Ersatzfernbedienung

	CD Play/Pause		Play
	CD Play/Pause		Pause
	TUNER Band		Smart
	TUNER P.Scan		Media
	TUNER P.Scan		Shift + Media
	EQ Effect		Ch -
	EQ M.Call		Ch +
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0



