















Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
	Power		Power
	Counter Reset		Media
	Goto Zero		Smart
	Rec		Rec
	Pause		Pause
	X2		Format
	II> Frame		Sleep
	X1/10		AV
	X1/5		3D
	Play		Play
	Search >>		>>
	<< Search		<<
	FF >>		>>I
	<< Rew		I<<
	Stop		Stop

