





| Originalfernbedienung | Ersatzfernbedienung |
|------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------|
|  Clock |  Info / Angle |
|  Timer |  Shift + Sleep / Timer |
|  Timer On/Off |  OK |
|  Power |  Power |
|  1/Down |  1 |
|  2/Up |  2 |
|  3/Set |  3 |
|  Sleep |  Sleep / Timer |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  Program |  TV/Radio / |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  Random |  Blue / Prime Video / Random |
|  10 |  0 |

| Originalfernbedienung | Ersatzfernbedienung |
|------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------|
|  +10 |  Guide / EPG / -/-- |
|  Auto Preset |  Setup / OPT / |
|  Repeat |  Green / APP / Repeat |
|  AUX |  Shift + 7 |
|  Play/Pause CD |  Play / Slow |
|  <> Tape |  Pause / Step / Freeze |
|  Tuner Band/FM |  Audio / Lang I/II |
|  Reverse Mode |  Back / Return |
|  I<</REW |  I<< / Preset- |
|  Stop |  Stop / Hold |
|  >>I/FF |  >>I / Preset+ |
|  Display |  Display / Media |
|  Sound |  Sound / Title |
|  ACS |  Smart / List |
|  Super Woofer Volume- |  CH- / Page- |
|  Super Woofer Volume+ |  CH+ / Page+ |
|  Volume- |  Vol- |





| | Originalfernbedienung | Ersatzfernbedienung | | Originalfernbedienung | Ersatzfernbedienung |
|-----------------------------------------------------------------------------------|-----------------------|-----------------------------------------------------------------------------------|------|-----------------------|---------------------|
|  | Volume+ |  | Vol+ | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

