





































Originalfernbedienung Ersatzfernbedienung

|   |        |   |                   |
|---|--------|---|-------------------|
|    | Mute   |    | Mute / Dimmer     |
|    | Power  |    | Power             |
|    | PP     |    | Back / Return     |
|    | I / II |    | Audio / Lang I/II |
|    | 1      |    | 1                 |
|    | 2      |    | 2                 |
|    | 3      |    | 3                 |
|    | 4      |    | 4                 |
|    | 5      |    | 5                 |
|    | 6      |    | 6                 |
|   | 7      |   | 7                 |
|  | 8      |  | 8                 |
|  | 9      |  | 9                 |
|  | 0      |  | 0                 |
|  | --     |  | Fav / Marker / PC |
|  | P<P    |  | Display / Media   |
|  | Menu   |  | Menu / Home       |

Originalfernbedienung Ersatzfernbedienung

|   |                  |   |                             |
|---|------------------|---|-----------------------------|
|    | Info             |    | Info / Angle                |
|    | Left             |    | Left                        |
|    | Up / P +         |    | Up                          |
|    | Up / P +         |    | CH+ / Page+                 |
|    | Right            |    | Right                       |
|    | Down / P -       |    | Down                        |
|    | Down / P -       |    | CH- / Page-                 |
|    | Vol -            |    | Vol-                        |
|    | Vol +            |    | Vol+                        |
|    | Red / Sound      |    | Red / Netflix / Search      |
|   | Green / Picture  |   | Green / APP / Repeat        |
|  | Yellow / Feature |  | Yellow / YouTube / Repeat   |
|  | Blue / Install   |  | Blue / Prime Video / Random |
|  | TV               |  | TV/Radio /                  |
|  | AV               |  | AV / Input / RDS            |
|  | Text             |  | Text / Goto                 |
|  | Mix              |  | Shift + Text / Goto         |



