



















Originalfernbedienung Ersatzfernbedienung

|   |            |   |                       |
|---|------------|---|-----------------------|
|    | Standby/On |    | Power                 |
|    | 1          |    | 1                     |
|    | 2          |    | 2                     |
|    | 3          |    | 3                     |
|    | 4          |    | 4                     |
|    | 5          |    | 5                     |
|    | 6          |    | 6                     |
|    | 7          |    | 7                     |
|    | 8          |    | 8                     |
|    | 9          |    | 9                     |
|   | 0          |   | 0                     |
|  | Clear      |  | Exit / Cancel / Clear |
|  | Play Mode  |  | Shift + Play /        |
|  | Top Menu   |  | D.Menu / Top          |
|  | Up         |  | Up                    |
|  | Menu       |  | Menu / Home           |
|  | Left       |  | Left                  |

Originalfernbedienung Ersatzfernbedienung

|   |            |   |                       |
|---|------------|---|-----------------------|
|    | Right      |    | Right                 |
|    | Down       |    | Down                  |
|    | Home Menu  |    | Shift + Menu /        |
|    | Home Menu  |    | Smart / List          |
|    | Return     |    | Back / Return         |
|    | Enter      |    | OK                    |
|    | Stop       |    | Stop / Hold           |
|    | <</<  />   |    | << / Tune-            |
|    | Play       |    | Play / Slow           |
|    | >/  />>    |    | >> / Tune+            |
|   | I<<        |   | I<< / Preset-         |
|  | Pause      |  | Pause / Step / Freeze |
|  | >>I        |  | >>I / Preset+         |
|  | Audio      |  | Audio / Lang I/II     |
|  | Subtitle   |  | Subtitle / EQ         |
|  | Angle      |  | Info / Angle          |
|  | Open/Close |  | Eject / Surround      |



