







































Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	SAT		Smart
	Tv/R		TV/R
	Menu		Menu
	Exit		Exit
	Up		Up

Originalfernbedienung Ersatzfernbedienung

	Left		Left
	OK		Ok
	Right		Right
	Down		Down
	FAV		Pre Ch
	EPG		Guide
	V+		Vol +
	V-		Vol -
	Info		Info
	Audio		Dual
	Text		Text
	P+		Ch +
	P-		Ch -
	Red		Red
	RCL		Options
	Green/Pause		Green
	Yellow		Yellow





Originalfernbedienung Ersatzfernbedienung



	SUB		Subt
	V.F		3D
	Blue		Blue
	Pause		Pause
	<I		I<<
	I>		>>I
	Rec		Rec
	Play		Play
	<<		<<
	>>		>>
	Stop		Stop

Originalfernbedienung Ersatzfernbedienung







































Originalfernbedienung Ersatzfernbedienung

















	Power		Power
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	SAT		Smart
	Tv/R		TV/R
	Menu		Menu
	Exit		Exit
	Up		Up

Originalfernbedienung Ersatzfernbedienung

	Left		Left
	OK		Ok
	Right		Right
	Down		Down
	FAV		Pre Ch
	EPG		Guide
	V+		Vol +
	V-		Vol -
	Info		Info
	Audio		Dual
	Text		Text
	P+		Ch +
	P-		Ch -
	Red		Red
	RCL		Options
	Green/Pause		Green
	Yellow		Yellow




Originalfernbedienung Ersatzfernbedienung





	SUB		Subt
	V.F		3D
	Blue		Blue
	Pause		Pause
	<		I<<
	>		>>
	Rec		Rec
	Play		Play
	<<		<<
	>>		>>
	Stop		Stop

Originalfernbedienung Ersatzfernbedienung







































Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	SAT		Smart
	Tv/R		TV/R
	Menu		Menu
	Exit		Exit
	Up		Up


Originalfernbedienung Ersatzfernbedienung

	Left		Left
	OK		Ok
	Right		Right
	Down		Down
	FAV		Pre Ch
	EPG		Guide
	V+		Vol +
	V-		Vol -
	Info		Info
	Audio		Dual
	Text		Text
	P+		Ch +
	P-		Ch -
	Red		Red
	RCL		Options
	Green/Pause		Green
	Yellow		Yellow





Originalfernbedienung Ersatzfernbedienung

	SUB		Subt
	V.F		3D
	Blue		Blue
	Pause		Pause
	<		I<<
	>		>>I
	Rec		Rec
	Play		Play
	<<		<<
	>>		>>
	Stop		Stop

Originalfernbedienung Ersatzfernbedienung

