














Originalfernbedienung Ersatzfernbedienung

|   |        |   |                            |
|---|--------|---|----------------------------|
|    | Power  |    | Power                      |
|    | Mute   |    | Mute / Dimmer              |
|    | 1      |    | 1                          |
|    | 2      |    | 2                          |
|    | 3      |    | 3                          |
|    | 4      |    | 4                          |
|    | 5      |    | 5                          |
|    | 6      |    | 6                          |
|    | 7      |    | 7                          |
|    | 8      |    | 8                          |
|   | 9      |   | 9                          |
|  | 0      |  | 0                          |
|  | -/--   |  | Shift + Guide / EPG / -/-- |
|  | Recall |  | Back / Return              |
|  | P.Mode |  | Picture / Format           |
|  | S.Mode |  | Sound / Title              |
|  | Sleep  |  | Sleep / Timer              |

Originalfernbedienung Ersatzfernbedienung

|   |          |   |                       |
|---|----------|---|-----------------------|
|    | Nicam    |    | Audio / Lang I/II     |
|    | Menu     |    | Menu / Home           |
|    | Up       |    | Up                    |
|    | Source   |    | AV / Input / RDS      |
|    | Left     |    | Left                  |
|    | OK       |    | OK                    |
|    | Right    |    | Right                 |
|    | Down     |    | Down                  |
|    | Exit     |    | Exit / Cancel / Clear |
|    | Display  |    | Display / Media       |
|   | Vol+     |   | Vol+                  |
|  | CH+      |  | CH+ / Page+           |
|  | Vol-     |  | Vol-                  |
|  | List     |  | Smart / List          |
|  | FAV/List |  | Fav / Marker / PC     |
|  | CH-      |  | CH- / Page-           |
|  | Tv/Radio |  | TV/Radio /            |



