



































































Originalfernbedienung Ersatzfernbedienung

	Power		Power
	V-Format		Format
	TV / Sat		Shift + TV/R
	Sleep		Sleep
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0 / Zoom		0
	0 / Zoom		Eject
	TV / Radio		TV/R

Originalfernbedienung Ersatzfernbedienung

	Recall		Back
	P +		Ch +
	P -		Ch -
	Find		List
	Folder		Shift + List
	V +		Vol +
	V -		Vol -
	Menu		Menu
	Info		Info
	Up		Up
	Right		Right
	Down		Down
	Left		Left
	OK		Ok
	Exit		Exit
	EPG		Guide
	Portal		Smart





Originalfernbedienung Ersatzfernbedienung

	FAV		Pre Ch
	SAT		AV
	Red / Audio		Red
	Red / Audio		Dual
	Green / Option		Green
	Green / Option		Options
	Yellow / TXT		Yellow
	Yellow / TXT		Text
	Blue		Blue
	Record		Rec
	Stop		Stop
	Pause		Pause
	Play		Play
	I<< Prev		I<<
	Next >>I		>>I
	<< / Page -		<<
	>> / Page +		>>

Originalfernbedienung Ersatzfernbedienung

	<I		Shift + Left
	I>		Shift + Right
	Play Mode		Shift + Play
	USB		Media
	TimeShift		3D
	F1		Shift + 1
	F2		Shift + 2
	F3		Shift + 3

