



Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Optical		Smart / List
	Vol+		Vol+
	Vol-		Vol-
	Mute		Mute / Dimmer
	EQ.		Setup / OPT /
	Woofer Level		CH+ / Page+
	Woofer Level		CH- / Page-
	Bluetooth		9
	LG TV		TV/Radio /
	PORT.IN		Picture / Format
	Sound Effect		Sound / Title
	*)		Down
	Left		Left
	Right		Right
	AV Sync		OK
	DRC		Menu / Home

Originalfernbedienung Ersatzfernbedienung

	Info		Info / Angle
	Sleep		Sleep / Timer
	Auto Volume		Audio / Lang I/II
	Auto Power		Exit / Cancel / Clear

