






























































Originalfernbedienung Ersatzfernbedienung

	On/Standby		Power
	Dimmer		Subt
	Clock		Back
	Sleep		Sleep
	Favorite		Pre Ch
	Internet Radio		Media
	Music Server		Dual
	Online Music		3D
	iPod/USB		Blue
	M-XPort		AV
	Tuner		Red
	Disc		Green
	AUX		Yellow
	I<<		I<<
	Play		Play
	Pause		Pause
	>>I		>>I

Originalfernbedienung Ersatzfernbedienung

	<</Tuning-		<<
	Stop		Stop
	>>/Tuning+		>>
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	CH+		Ch +
	CH-		Ch -
	DBB/Tone		List
	Menu		Menu
	Mode		D. Menu
	Search		TV/R
	Home		Smart
	Up		Up
	Down		Down
	Right		Right
	Left		Left



