



Originalfernbedienung Ersatzfernbedienung

|   |                  |   |                       |
|---|------------------|---|-----------------------|
|    | Power            |    | Power                 |
|    | Mute             |    | Mute / Dimmer         |
|    | Play             |    | Play / Slow           |
|    | Pause            |    | Pause / Step / Freeze |
|    | Stop             |    | Stop / Hold           |
|    | Rec              |    | Rec / Rec Mode        |
|    | <<               |    | << / Tune-            |
|    | >>               |    | >> / Tune+            |
|    | Lang             |    | Audio / Lang I/II     |
|    | Source (Games)   |    | Eject / Surround      |
|   | Movie-Music-Phot |   | Picture / Format      |
|  | [≡]..            |  | Zoom / Size           |
|  | * / O            |  | Sleep / Timer         |
|  | TV               |  | TV/Radio /            |
|  | Q.Menu           |  | D.Menu / Top          |
|  | [-O-]            |  | Setup / OPT /         |
|  | [≡]/Text         |  | Text / Goto           |

Originalfernbedienung Ersatzfernbedienung

|   |                |   |                       |
|---|----------------|---|-----------------------|
|    | Menu           |    | Menu / Home           |
|    | Up             |    | Up                    |
|    | i              |    | Info / Angle          |
|    | Left           |    | Left                  |
|    | OK             |    | OK                    |
|    | Right          |    | Right                 |
|    | Exit           |    | Exit / Cancel / Clear |
|    | Down           |    | Down                  |
|    | Back           |    | Back / Return         |
|    | Vol+           |    | Vol+                  |
|   | World (Violet) |   | Smart / List          |
|  | PR+            |  | CH+ / Page+           |
|  | Vol-           |  | Vol-                  |
|  | * / Q          |  | Display / Media       |
|  | PR-            |  | CH- / Page-           |
|  | 1              |  | 1                     |
|  | 2              |  | 2                     |





Originalfernbedienung Ersatzfernbedienung

|        |        |                             |                             |
|--------|--------|-----------------------------|-----------------------------|
| 3 def  | 3      | CD - STB<br>3               | 3                           |
| 4 ghi  | 4      | VIDEO<br>4                  | 4                           |
| 5 jkl  | 5      | TAPE<br>5                   | 5                           |
| 6 mno  | 6      | TUNER<br>6                  | 6                           |
| 7 pqrs | 7      | AUX - HDD<br>7              | 7                           |
| 8 tuv  | 8      | USB<br>8                    | 8                           |
| 9 wxyz | 9      | BLUETOOTH<br>9              | 9                           |
| Guide  | Guide  | Guide / EPG / -/--          | Guide / EPG / -/--          |
| 0      | 0      | HDMI - BAT<br>0             | 0                           |
|        | Red    | Red / Netflix / Search      | Red / Netflix / Search      |
|        | Green  | Green / APP / Repeat        | Green / APP / Repeat        |
|        | Yellow | Yellow / YouTube / Repeat   | Yellow / YouTube / Repeat   |
|        | Blue   | Blue / Prime Video / Random | Blue / Prime Video / Random |
|        | Recall | Shift + Back / Return       | Shift + Back / Return       |
|        |        |                             |                             |
|        |        |                             |                             |
|        |        |                             |                             |
|        |        |                             |                             |
|        |        |                             |                             |

Originalfernbedienung Ersatzfernbedienung

|  |  |  |  |
|--|--|--|--|
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |

