
























Originalfernbedienung Ersatzfernbedienung

| | | | |
|---|-------------------|---|---------|
|  | Power |  | Power |
|  | Subwoofer+ |  | Ch + |
|  | Subwoofer- |  | Ch - |
|  | Dimmer |  | Media |
|  | Sound |  | Dual |
|  | Vol+ |  | Vol + |
|  | Vol- |  | Vol - |
|  | Mute |  | Mute |
|  | HDMI(ARC) |  | AV |
|  | Optical |  | Options |
|  | Bluetooth/Pairing |  | Smart |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

Originalfernbedienung Ersatzfernbedienung

| | | | |
|--|--|--|--|
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

