



Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Info		Info
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0 / Zoom		0
	0 / Zoom		Eject
	Audio		Dual
	Mute		Mute
	Recall		Back
	FAV		Pre Ch

Originalfernbedienung Ersatzfernbedienung

	Up / CH+		Up
	Up / CH+		Ch +
	Down / CH-		Down
	Down / CH-		Ch -
	Right / Vol+		Right
	Right / Vol+		Vol +
	Left / Vol-		Left
	Left / Vol-		Vol -
	OK		Ok
	Menu		Menu
	Exit		Exit
	Blue / Pause		Blue
	Blue / Pause		Pause
	Red / Text		Red
	Red / Text		Text
	Multivideo		Smart
	Yellow / Subtitle		Yellow





Originalfernbedienung Ersatzfernbedienung



















	Yellow / Subtitle	AD SUBT	Subt
	TV / AV	TIMER AV	AV
	Green / P/N	B	Green
	SAT	APP MEDIA	Media
	TV / Radio	SEARCH TV/R	TV/R
	EPG	- / - GUIDE	Guide

Originalfernbedienung Ersatzfernbedienung






































Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	TV/SAT		AV
	TV/Radio		TV/R
	Zoom		Eject
	List		List
	Audio		Dual
	EPG		Guide
	Timer		Shift + AV
	Text		Text
	Exit		Exit
	Menu		Menu
	M/P		Media
	Mute		Mute

Originalfernbedienung Ersatzfernbedienung

	CH+		Ch +
	CH-		Ch -
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Vol+		Vol +
	Vol-		Vol -
	P+		>>
	P-		<<
	Recall		Pre Ch
	FAV		Shift + Pre Ch
	1		1
	2		2
	3		3
	4		4



