



























































Originalfernbedienung Ersatzfernbedienung

	Standby/On		Power
	Eject		Eject / Surround
	1/Slow-		1
	2		2
	3/Slow+		3
	4/Shuttle-		4
	5		5
	6/Shuttle+		6
	7/V-Lock Down		7
	8		8
	9/V-Lock Up		9
	CLR/RST		Exit / Cancel / Clear
	0/F.ADV		0
	Index		Info / Angle
	A-TRK		Smart / List
	IPC		D.Menu / Top
	Input		AV / Input / RDS











Originalfernbedienung Ersatzfernbedienung

	Repeat		Green / APP / Repeat
	Audio		Audio / Lang I/II
	TRK+		>>I / Preset+
	Prog+		CH+ / Page+
	Display		Display / Media
	TRK-		I<< / Preset-
	Prog-		CH- / Page-
	<<		<< / Tune-
	Stop		Stop / Hold
	Play		Play / Slow
	Pause		Pause / Step / Freeze
	>>		>> / Tune+
	Rec		Rec / Rec Mode
	Menu		Menu / Home
	Up		Up
	Left		Left
	OK		OK





Originalfernbedienung Ersatzfernbedienung

	Right		Right
	Down		Down
	Speed		Picture / Format
	DUB		Sound / Title
	TV/VCR		TV/Radio /
	Timer		Sleep / Timer

Originalfernbedienung Ersatzfernbedienung

