





































Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Mute		Mute
	Red/IPTV		Red
	Green/VOD		Green
	Yellow/YouTube		Yellow
	Blue/Quran		Blue
	<<		<<
	>>		>>
	I<<		I<<
	>>I		>>I
	Play		Play
	Pause		Pause
	Stop		Stop
	SAT		Smart
	Media		Media
	Timer		AV
	Recall		Back

Originalfernbedienung Ersatzfernbedienung

	Audio		Dual
	EPG		Guide
	i		Info
	Menu		Menu
	Exit		Exit
	FAV		Pre Ch
	Rec		Rec
	Up		Up
	OK		Ok
	Down		Down
	Right		Right
	Left		Left
	Vol+		Vol +
	Vol-		Vol -
	Page+		Ch +
	Page-		Ch -
	1		1





Originalfernbedienung Ersatzfernbedienung

Originalfernbedienung	Ersatzfernbedienung
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
SUBTITLE	AD SUBT
TV/RADIO	SEARCH TV/R


















Originalfernbedienung Ersatzfernbedienung

Originalfernbedienung	Ersatzfernbedienung






















Originalfernbedienung Ersatzfernbedienung

Power		Power
Mute		Mute
1		1
2		2
3		3
4		4
5		5
6		6
7		7
8		8
9		9
0		0
Vol+		Vol +
Vol-		Vol -
TV/R		TV/R
Page+		Ch +
Page-		Ch -

Originalfernbedienung Ersatzfernbedienung

IPTV		Media
VOD		Smart
Info		Info
Menu		Menu
Exit		Exit
Recall		Back
Up		Up
Down		Down
OK		Ok
Right		Right
Left		Left
Red/YouTube		Red
Green		Green
Yellow		Yellow
Blue/Quran		Blue
Audio		Dual
TTX/CC		Text



