





































































Originalfernbedienung Ersatzfernbedienung

	Power		Power
	P.Mode	 + 	Shift + Format
	S.Mode	 + 	Shift + Dual
	I/II		Dual
	Sleep		Sleep
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	10+		Guide
	Back		Back

Originalfernbedienung Ersatzfernbedienung

	Source		AV
	Menu		Menu
	Info		Info
	Exit		Exit
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	Aspect		3D
	CH+		Ch +
	CH-		Ch -
	Play/Pause/EPG		Play
	Stop/FAV		Stop





Originalfernbedienung		Ersatzfernbedienung		Originalfernbedienung		Ersatzfernbedienung	
	Eject/Add/Del		Pre Ch				
	Media		Media				
	[.] <</TTX		Text				
	[≡x] <</Cancel		TV/R				
	[≡♦]/Title/Size		Format				
	Subtitle		Subt				
	[≡+] />> /Hold		Options				
	[≡?] >>/Reveal		Eject				
	[≡o]/Menu/Subpa		D. Menu				
	[≡i]/Audio/Index		List				
	Red/Goto		Red				
	Green/Slow		Green				
	Yellow/Repeat		Yellow				
	Blue/A-B		Blue				
	DVD Setup		Smart				

