








Originalfernbedienung Ersatzfernbedienung

| | | | |
|---|----------|---|----------------------------|
|  | Power |  | Power |
|  | AV Mode |  | AV / Input / RDS |
|  | Radio |  | TV/Radio / |
|  | Surround |  | Eject / Surround |
|  | DTV |  | Shift + TV/Radio / Program |
|  | Mute |  | Mute / Dimmer |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | Vol+ |  | Vol+ |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | Vol- |  | Vol- |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |

Originalfernbedienung Ersatzfernbedienung

| | | | |
|---|-----------|---|---------------------------|
|  | PR+ |  | CH+ / Page+ |
|  | Recall |  | Back / Return |
|  | 0 |  | 0 |
|  | Source |  | Shift + AV / Input / RDS |
|  | PR- |  | CH- / Page- |
|  | [<>] |  | Picture / Format |
|  | I/II/I+II |  | Zoom / Size |
|  | [i+] |  | Info / Angle |
|  | Sleep |  | Sleep / Timer |
|  | EPG |  | Guide / EPG / -/- |
|  | ESG |  | Setup / OPT / |
|  | DTV Menu |  | Shift + D.Menu / Top Menu |
|  | [≡]/Text |  | Text / Goto |
|  | Up |  | Up |
|  | Menu |  | Menu / Home |
|  | Left |  | Left |
|  | OK |  | OK |





Originalfernbedienung Ersatzfernbedienung

| | | | |
|--|--------|--|-----------------------------|
| | Right | | Right |
| | END | | Exit / Cancel / Clear |
| | Down | | Down |
| | Return | | Shift + Back / Return |
| | [≐?] | | Shift + Info / Angle |
| | [≐+] | | Stop / Hold |
| | [...] | | Subtitle / EQ |
| | [≐o] | | D.Menu / Top |
| | Red | | Red / Netflix / Search |
| | Green | | Green / APP / Repeat |
| | Yellow | | Yellow / YouTube / Repeat |
| | Blue | | Blue / Prime Video / Random |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

Originalfernbedienung Ersatzfernbedienung

| | | | |
|--|--|--|--|
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

