



















































Originalfernbedienung Ersatzfernbedienung
















	Power		Power
	Optical		1
	Optical		Red / Netflix / Search
	Mute		Mute / Dimmer
	AUX		7
	AUX		Green / APP / Repeat
	BT		9
	BT		Yellow / YouTube / Repeat
	HDMI ARC		0
	HDMI ARC		Blue / Prime Video / Random
	Vol+		Vol+
	Vol+		Up
	I<		I<< / Preset-
	I<		Left
	Play/Pause / Pair		OK
	Play/Pause / Pair		Play / Slow
	Play/Pause / Pair		Pause / Step / Freeze

Originalfernbedienung Ersatzfernbedienung

	>I		>>I / Preset+
	>I		Right
	Vol-		Vol-
	Vol-		Down
	News		Audio / Lang I/II
	Movie		Picture / Format
	Music		Sound / Title





Originalfernbedienung		Ersatzfernbedienung		Originalfernbedienung		Ersatzfernbedienung	
Power		Power					
Bluetooth		9					
Source		AV / Input / RDS					
Vol+		Vol+					
Vol-		Vol-					
Mute		Mute / Dimmer					
>>I		>>I / Preset+					
I<<		I<< / Preset-					
Play/Pause		Play / Slow					
Play/Pause		Pause / Step / Freeze					
Bass+		Right					
Bass-		Left					
EQ		Subtitle / EQ					
Tre+		Up					
Tre-		Down					

