



Originalfernbedienung	Ersatzfernbedienung
	On
	SRC / Search
	OFF
	Auto / Mode
	Menu / Info
	-- / USB
	Up
	Down
	Right
	Left
	OK
	Exit / Lamp
	Aspect / Re-Sync
	Hide / Blank
	K.S. / PIP
	LAN
	Mute / Focus

Originalfernbedienung	Ersatzfernbedienung
	Pict / Freeze
	Vol +
	Vol -
	KS Up
	KS Down

