


Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Power AMP		Shift + Power
	CD		Red
	Recorder		Green
	Network		Yellow
	Phono		Blue
	AUX		Smart
	Tuner		Media
	Internet Radio Preset 1		Shift + 1
	Internet Radio Preset 2		Shift + 2
	Internet Radio Preset 3		Shift + 3
	Play		Play
	Pause		Pause
	I<<		I<<
	>>I		>>I
	Stop		Stop
	<<		<<

Originalfernbedienung Ersatzfernbedienung

	>>		>>
	Preset+		Ch +
	Preset-		Ch -
	Pure Direct/Favorite		Pre Ch
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	Info		Info
	Mode		Format
	Source		AV
	Menu		Menu
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Enter		Ok
	1		1





Originalfernbedienung Ersatzfernbedienung

2 ABC	2	2	2
3 DEF	3	3	3
4 GHI	4	4	4
5 JKL	5	5	5
6 MNO	6	6	6
7 PQRS	7	7	7
8 TUV	8	8	8
9 WXYZ	9	9	9
0 . _L . _R	0	0	0
+10	+10	GUIDE	Guide
CLEAR	Clear	CLEAR EXIT	Exit
RANDOM	Random	SETTINGS OPT	Options
REPEAT	Repeat	REPEAT TEXT	Text
PROGRAM SEARCH	Search/Program	PROG SLEEP	Sleep
DIMMER	Dimmer	SOUND DUAL	Dual

Originalfernbedienung Ersatzfernbedienung





Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Power AMP		Shift + Power
	CD		Red
	Recorder		Green
	Network		Yellow
	Phono		Blue
	AUX		Smart
	Tuner		Media
	Play		Play
	Pause		Pause
	I<<		I<<
	>>I		>>I
	Stop		Stop
	<<		<<
	>>		>>
	Preset+		Ch +
	Preset-		Ch -

























Originalfernbedienung Ersatzfernbedienung

	Pure Direct/Favorite		Pre Ch
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	Info		Info
	Mode		Format
	Source		AV
	Menu		Menu
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Enter		Ok
	1		1
	2		2
	3		3
	4		4





Originalfernbedienung Ersatzfernbedienung

	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	+10		Guide
	Clear		Exit
	Random		Options
	Repeat		Text
	Search/Program		Sleep
	Dimmer		Dual

Originalfernbedienung Ersatzfernbedienung

