






















































Originalfernbedienung Ersatzfernbedienung

|   |          |   |                   |
|---|----------|---|-------------------|
|    | Input    |    | AV / Input / RDS  |
|    | Power    |    | Power             |
|    | 3D       |    | Setup / OPT /     |
|    | Text     |    | Text / Goto       |
|    | Subtitle |    | Subtitle / EQ     |
|    | O)/I/II  |    | Audio / Lang I/II |
|    | 1        |    | 1                 |
|    | 2        |    | 2                 |
|    | 3        |    | 3                 |
|    | 4        |    | 4                 |
|    | 5        |    | 5                 |
|   | 6        |   | 6                 |
|  | 7        |  | 7                 |
|  | 8        |  | 8                 |
|  | 9        |  | 9                 |
|  | AD       |  | Sound / Title     |
|  | 0        |  | 0                 |

Originalfernbedienung Ersatzfernbedienung

|   |           |   |                       |
|---|-----------|---|-----------------------|
|    | ATV/DTV   |    | Smart / List          |
|    | Vol+      |    | Vol+                  |
|    | [≡i]/[i+] |    | Info / Angle          |
|    | P+        |    | CH+ / Page+           |
|    | Vol-      |    | Vol-                  |
|    | Mute      |    | Mute / Dimmer         |
|    | P-        |    | CH- / Page-           |
|    | Quick     |    | Display / Media       |
|    | Guide     |    | Guide / EPG / -/-     |
|    | Up        |    | Up                    |
|    | Exit      |    | Exit / Cancel / Clear |
|   | Left      |   | Left                  |
|  | OK        |  | OK                    |
|  | Right     |  | Right                 |
|  | Menu      |  | Menu / Home           |
|  | Down      |  | Down                  |
|  | Return    |  | Back / Return         |





Originalfernbedienung   Ersatzfernbedienung

|   |            |   |                             |
|---|------------|---|-----------------------------|
|  | Red        |  | Red / Netflix / Search      |
|  | Green      |  | Green / APP / Repeat        |
|  | Yellow     |  | Yellow / YouTube / Repeat   |
|  | Blue       |  | Blue / Prime Video / Random |
|  | [≡?]       |  | Play / Slow                 |
|  | [≡□]       |  | Stop / Hold                 |
|  | [≡⇅]       |  | Zoom / Size                 |
|  | [⊖] / [≡X] |  | Pause / Step / Freeze       |
|   |            |   |                             |
|   |            |   |                             |
|   |            |   |                             |
|   |            |   |                             |
|   |            |   |                             |
|   |            |   |                             |
|   |            |   |                             |
|   |            |   |                             |
|   |            |   |                             |
|   |            |   |                             |
|   |            |   |                             |
|   |            |   |                             |
|   |            |   |                             |

Originalfernbedienung   Ersatzfernbedienung

|  |  |
|--|--|
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |

