



















































Originalfernbedienung Ersatzfernbedienung

| | | | |
|---|------------------|---|--------------|
|  | Power |  | Power |
|  | Mute |  | Mute |
|  | Mosaico |  | List |
|  | DVR / Gravações |  | Media |
|  | VOD / Videoclube |  | Smart |
|  | Pesquisa |  | Shift + TV/R |
|  | Exit |  | Exit |
|  | Menu |  | Menu |
|  | i |  | Info |
|  | Vol + |  | Vol + |
|  | Vol - |  | Vol - |
|  | Up |  | Up |
|  | Left |  | Left |
|  | OK |  | Ok |
|  | Right |  | Right |
|  | Down |  | Down |
|  | P + |  | Ch + |

Originalfernbedienung Ersatzfernbedienung

| | | | |
|---|-------------|---|--------|
|  | P - |  | Ch - |
|  | Stop |  | Stop |
|  | << |  | << |
|  | Pause |  | Pause |
|  | Play |  | Play |
|  | >> |  | >> |
|  | Rec |  | Rec |
|  | Red |  | Red |
|  | Green |  | Green |
|  | Yellow |  | Yellow |
|  | Blue |  | Blue |
|  | I<< |  | I<< |
|  | Back |  | Back |
|  | Radio / TXT |  | TV/R |
|  | Radio / TXT |  | Text |
|  | >>I |  | >>I |
|  | 1 |  | 1 |





Originalfernbedienung Ersatzfernbedienung

| | | | |
|---|----------|---|------------------|
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |
|  | 0 |  | 0 |
|  | GUIA / |  | Guide |
|  | * / AV |  | AV |
|  | # / -/-- |  | Shift + Guide |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

Originalfernbedienung Ersatzfernbedienung

| | | | |
|--|--|--|--|
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

