











































































































| Original | Replacement | Original | Replacement |
|--|---|--|---|
|  Power |  Power |  [=]/Source |  AV / Input / RDS |
|  Mute |  Mute / Dimmer |  Menu |  Menu / Home |
|  [=]/Text |  Text / Goto |  Up |  Up |
|  Play |  Play / Slow |  Left |  Left |
|  Pause |  Pause / Step / Freeze |  Enter |  OK |
|  [=+] |  Shift + Stop / |  Right |  Right |
|  Stop/Still |  Stop / Hold |  Down |  Down |
|  Radio |  TV/Radio / |  [=i]/Info |  Info / Angle |
|  Format |  Picture / Format |  Exit |  Exit / Cancel / Clear |
|  << |  << / Tune- |  Vol+ |  Vol+ |
|  Red |  Red / Netflix / Search |  Index |  Setup / OPT / |
|  >> |  >> / Tune+ |  CH+ |  CH+ / Page+ |
|  Green |  Green / APP / Repeat |  Vol- |  Vol- |
|  I<< |  I<< / Preset- |  List |  Smart / List |
|  Yellow |  Yellow / YouTube / Repeat |  CH- |  CH- / Page- |
|  >>I |  >>I / Preset+ |  1 |  1 |
|  Blue |  Blue / Prime Video / Random |  2 |  2 |





| Original | | Replacement | | Original | | Replacement | |
|---|---------------|---|--------------------|---|-----|---|----------------|
|  | 3 |  | 3 |  | Rec |  | Rec / Rec Mode |
|  | 4 |  | 4 | | | | |
|  | 5 |  | 5 | | | | |
|  | 6 |  | 6 | | | | |
|  | 7 |  | 7 | | | | |
|  | 8 |  | 8 | | | | |
|  | 9 |  | 9 | | | | |
|  | O)/Audio |  | Audio / Lang I/II | | | | |
|  | 0 |  | 0 | | | | |
|  | DVB |  | Display / Media | | | | |
|  | Fav ♥ |  | Fav / Marker / PC | | | | |
|  | Sleep |  | Sleep / Timer | | | | |
|  | EPG |  | Guide / EPG / -/-- | | | | |
|  | Back |  | Back / Return | | | | |
|  | [≡x] |  | D.Menu / Top | | | | |
|  | [≡o]/Subtitle |  | Subtitle / EQ | | | | |
|  | USB |  | Shift + 8 | | | | |

