








































































Original		Replacement		Original		Replacement	
	Power		Power		CH+		Ch +
	Mute		Mute		CH-		Ch -
	1		1		Up		Up
	2		2		Down		Down
	3		3		Right		Right
	4		4		Left		Left
	5		5		OK		Ok
	6		6		Exit		Exit
	7		7		Text		Text
	8		8		Menu		Menu
	9		9		Aspect		3D
	0		0		Size		Format
	--		Guide		Sleep		Sleep
	Recall		Pre Ch		Media		Media
	Source		AV		Reveal		Options
	Vol+		Vol +		Info		Info
	Vol-		Vol -		Tv/Radio		TV/R





	Original	Replacement		Original	Replacement
	I/II/Audio	 Dual			Repeat
	Subtitle	 Subt			
	Play	 Play			
	Pause	 Pause			
	Stop	 Stop			
	Rec	 Rec			
	I<<	 I<<			
	>>I/Index	 >>I			
	<</Subpage	 <<			
	>>/Hold	 >>			
	Red	 Red			
	Green	 Green			
	Yellow	 Yellow			
	Blue	 Blue			
	PIC Mode	 +  Shift + Format			
	S.Mode	 +  Shift + Dual			
	Rec Menu	 +  Shift + Rec			

