



Original		Replacement		Original		Replacement	
	Power		Power		Exit		Exit
	Mute		Mute		Up		Up
	1		1		Down		Down
	2		2		Right		Right
	3		3		Left		Left
	4		4		OK		Ok
	5		5		Vol+		Vol +
	6		6		Vol-		Vol -
	7		7		Sound		Shift + Dual
	8		8		PIC		Options
	9		9		CH+		Ch +
	0		0		CH-		Ch -
	Audio		Dual		Sleep		Sleep
	Recall		Back		Aspect		3D
	Tv-Menu		Menu		Freeze		Shift + Media
	Source		AV		Tv/Radio		TV/R
	CH.List		List		Text		Text



