























































Original	Replacement
	 Power
	 Source
	 Menu
	 D. Menu
	 TV/R
	 Guide
	 Smart
	 Text
	 Ok
	 Up
	 Down
	 Left
	 Right
	 Red
	 Green
	 Yellow
	 Blue

Original	Replacement
	 Eject
	 Back
	 Options
	 Play
	 Stop
	 Pause
	 <<
	 >>
	 I<<
	 >>I
	 Vol +
	 Vol -
	 Mute
	 1
	 2
	 3
	 4





Original	Replacement	Original	Replacement
 5	 5		
 6	 6		
 7	 7		
 8	 8		
 9	 9		
 0	 0		
 Subtitle	 Subt		
 Audio	 Dual		

