



Original	Replacement
Power	Power
AV	AV / Input / RDS
Mute	Mute / Dimmer
16:9	Picture / Format
Zoom	Zoom / Size
Subt.	Subtitle / EQ
Audio	Audio / Lang I/II
1	1
2	2
3	3
FAV	Fav / Marker / PC
4	4
5	5
6	6
EPG	Guide / EPG / -/--
7	7
8	8

Original	Replacement
9	9
Info	Info / Angle
Back	Back / Return
0	0
Exit	Exit / Cancel / Clear
Menu	Menu / Home
Up	Up
Left	Left
OK	OK
Right	Right
Down	Down
Vol-	Vol-
Vol+	Vol+
PR-	CH- / Page-
PR+	CH+ / Page+
Red	Red / Netflix / Search
Green	Green / APP / Repeat



