
























Original	Replacement
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Recall	 Pre Ch
 Sleep	 Sleep
 Screen	 Format
 Lang	 Dual
 Subttl	 Subt
 PIP	 3D

Original	Replacement
 EPG	 Guide
 FAV	 Shift + Pre Ch
 Presets	 Media
 [≡]/Text	 Text
 Mute	 Mute
 Source	 AV
 Menu	 Menu
 Info/?	 Info
 Return	 Back
 OK	 Ok
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Vol-	 Vol -
 Vol+	 Vol +
 P+	 Ch +



