



































































































Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute
	Info		Info
	Angle		Back
	Copy		Sleep
	Zoom		Eject
	Tv Sys		TV/R
	Music		Shift + Menu
	Setup		Options
	Menu		Menu
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Time Shift		Guide
	Goto		Pre Ch
	Rec		Rec
	Stop		Stop
	<</FR		<<
	>>/FF		>>
	Play/Pause		Play
	>>I/Next		>>I
	Subtitle		Subt
	Audio		Dual
	I<</Prev		I<<
	A-B		Shift + Play
	Repeat		Text
	Vol+		Vol +





Original		Replacement		Original		Replacement	
	Vol-		Vol -				
	Home		Smart				
	X/Return		Exit				
	Up		Up				
	Down		Down				
	Right		Right				
	Left		Left				
	Enter		Ok				
	Wuaki TV		AV				
	Select		List				
	Red		Red				
	Green/EPG		Green				
	Yellow/TTX		Yellow				
	Blue		Blue				

