













































































Original	Replacement
 Power	 Power
 Tv/AV	 AV
 Exit	 Exit
 Format	 Format
 TDT Menu Tv	 Menu
 Sound	 Dual
 Timer	 Shift + AV
 Picture	 Shift + Format
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9

Original	Replacement
 0	 0
 Return	 Back
 -/--	 Guide
 Vol+	 Vol +
 Vol-	 Vol -
 Display	 Shift + Info
 Sys-Menu	 Smart
 OK	 Ok
 Up	 Up
 CH+	 Ch +
 CH-	 Ch -
 Down	 Down
 Right	 Right
 Left	 Left
 Red/Prog/Tv/Radi	 Red
 Green/Slow/Audio	 Green
 Yellow/REP/Freeze	 Yellow





	Original	Replacement		Original	Replacement
	 Blue/A-B/Subtitle	 Blue		 Nicam/A2	 Media
	 Play/Pause/Hold	 Play			
	 Stop/Size	 Stop			
	 <</Language	 <<			
	 >>/Text	 >>			
	 I<</FAV	 I<<			
	 >>I/EPG	 >>I			
	 Eject/Index	 Rec			
	 Goto/Subpage	 Pre Ch			
	 Title/Info	 Info			
	 Mute	 Mute			
	 ANG/Exit/Reveal	 +  Shift + Exit			
	 SUBT	 Subt			
	 Zoom/	 3D			
	 Lang/TDTProg-	 Sleep			
	 Menu/TvFormat/Cancel	 TV/R			
	 Set/TDT-Menu/Tv/	 Text			



TXT