





































































Original	Replacement	Original	Replacement
	Power		Power
	Tv/AV		AV
	?		Smart
	Mute		Mute
	0		0
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	-/--		Guide
	Lock		Pre Ch
	Zoom		Eject
	Hold		Subt
	→ P ←		Format
	Mix		Media
	Text		Text
	Subcode		Options
	QV		TV/R
	→ S ←		Dual
	Cancel		Exit
	Reveal		Back
	Yellow/Timer		Yellow
	Blue/Sound		Blue
	Red/Picture		Red
	Green/Clock		Green
	Up		Up
	Down		Down
	Right		Right
	Left		Left



