





































































































Original		Replacement		Original		Replacement	
	Power		Power		Green		Green
	Play		Play		Yellow		Yellow
	Pause		Pause		Blue		Blue
	<<		<<		CH+		Ch +
	>>		>>		CH-		Ch -
	I<<		I<<		Vol+		Vol +
	>>I		>>I		Vol-		Vol -
	Stop		Stop		Source		AV
	Rec		Rec		Menu		Menu
	Tv/TXT		Text		DVB		Smart
	Cancel		Back		Exit		Exit
	Reveal		D. Menu		Up		Up
	Hold		Options		Down		Down
	Size		Eject		Right		Right
	Subpage		Shift + Subt		Left		Left
	Index		Info		OK		Ok
	Red		Red		1		1





Original	Replacement	Original	Replacement
 2	 2		
 3	 3		
 4	 4		
 5	 5		
 6	 6		
 7	 7		
 8	 8		
 9	 9		
 0	 0		
 -/--	 SHIFT +  Guide		
 Recall	  Pre Ch		
 PICTURE	  Shift + Format		
 SOUND	  Shift + Dual		
 NICAM/A2	 APP MEDIA Media		
 MUTE	 MUTE Mute		
 SLEEP	 PROG SLEEP Sleep		
 TV/RADIO	 SEARCH TV/R TV/R		

Original	Replacement	Original	Replacement
 FAV	  Shift + Pre Ch		
 FAV+	  Shift + Ch +		
 FAV-	  Shift + Ch -		
 Subtitle	 AD SUBT Subt		
 Pic Format	 PICTURE FORMAT Format		
 Language	 SOUND DUAL Dual		
 EPG	  Guide		
 Text	 DISC NAV LIST List		
 Display	 ECO 3D 3D		

